

# **TRA Transformers**




**TRA transformers series** are current transformers specially designed for being installed at the top of a circuit breaker. All the models have secondary of 250 mA and are suitable for SEM One, SEM Three and third-party devices.

**TRA transformers** are perfect for facilities with reduced spaces, using the space over the differential protections. Furthermore, TRA Transformers series are ideal for facilities whether it is not possible to stop the supply, or it just need a simple installation.

## **TECHNICAL FEATURES**

Electrical features				
Frequency	50 / 60 Hz			
Secondary's current	250 mA			
Measure	Single phase			
TRA series power class	1			
Build features				
Type of enclosure material	Ероху			

### **CONNECTIONS**




### INSTALLATION

The installation of the transformers must be done at the top of the circuit breaker protections.



# **GRAPHIC REPRESENTATIONS AND DIMENSIONS**



# **REFERENCES**

Model	Reference	Maximum current	Power class	Inner diameter
TRA1 20A	T024	20 A	1	16 mm
TRA1 80A	T004	80 A	1	10 mm
TRA1 100A	T005	100 A	1	16 mm
TRA1 250A	T025	250 A	1	24 mm



### SAFETY PRECAUTIONS

### **DANGER**



Incorrect handling or installation of the unit may result in injury to personnel as well as damage to the unit. In particular, handling with voltages applied may result in electric shock, which may cause death or serious injury to personnel. Defective installation or maintenance may also lead to the risk of fi re. Read the manual carefully prior to connecting the unit. Follow all installation and maintenance instructions throughout the unit's working life. Pay special attention to the installation standards of the National Electrical Code.

### **DISCLAIMER**

PickData, SL reserves the right to make modifications to the device or the unit specifications set out in this instruction manual without prior notice.

PickData, SL on its web site, supplies its customers with the latest versions of the device specifications and the most updated manuals.

### TECHNICAL SERVICE AND SUPPORT

The unit does not require maintenance.

In case any doubt of performance or failure of the unit do not hesitate to contact with PickData, SL support service.

PickData, SL - Technical assistance service

Innovació Street, 3 08232 – Viladecavalls (Barcelona), SPAIN Phone: (34) 935 117 505 (Spain) Email: sat@pickdata.net

V03-310119